

Framery O, Q, 2Q Cleaning Guide



1. Exterior

Wipe metal body covers using a mildly alkaline all-purpose detergent for cleaning.

2. Glasses

Clean the glasses with standard glass cleaning solution.

3. Ventilation shaft

Vacuum clean the ventilation shaft.

4. Fabrics (stool & sofas) Carpet

Vacuum clean the interiors.

We use wool in our fabrics. Wool is naturally resistant to dirt.

For woollen textiles we recommended dry cleaning or professional cleaning.

Alcohol-based disinfectants can be used without damaging the textiles or changing its colour. Concentration should be between 70-85%.

Avoid chlorine-based and bleach cleanable solutions.

We do not recommend washing woollen textiles.

5. Frames, Table, Felts and Door handle

Vacuum clean the felt.

Use a mildly alkaline all-purpose detergent for cleaning.

Alcohol-based disinfectants can also be used. (For example Framery Disinfectant Spray)

In extreme circumstances, a 1% chlorine-based solution may be used for table tops.

Apply a small amount of the solution to a cloth and wipe the surface gently. Avoid rubbing, as it might lead to discoloration.